


Fence Mount Upgrade for HangTight Banner Frames


Use these instructions together with HangTight Installation instructions

The Fence Mount Upgrade installs similar to a standard Flat wall HangTight with respect to spacing of the tracks. Instead of fastening the tracks directly to a wall surface, the Fence Mount Upgrade uses a matching set of shallow backing tracks that bolt to them on the opposite side of the fence.



Mark for Track Positions

Lay out your display and measure for track spacing as outlined in the attached HangTight Instructions for your size and style model. Make marks for track placement.



Fasten Tracks to Fence

Fasten each track to the fence by aligning it with its matching shallow track on the opposite side of the fence. Align holes and attach with the bolts, washers and nuts provided.

Tighten the nuts very securely.

You are now ready to install your banner. Please refer to separate instructions, "Installing the Banner" attached.




Figure shows 7" Live End track. Repeat this for all tracks for your size model.

Manufactured in the USA by

VOXPOP
MARKETING SYSTEMS

10746 Worcester Highway P.O. Box 200
Berlin, MD 21811 800-386-9767
www.voxpopms.com

Questions? Problems? Call Voxpop for assistance.

1-800-386-9767

or e-mail service@voxpopms.com