


# Pole Mount Frame - Clamp Bar Style Arms Installing The Banner

1.



Lay out your banner and the Live End and Dead End arms as shown. The printed side of the banner should be facing up. The black Thumb screws of the arms should be facing up.

2.



Make sure the black thumb screws are retracted far enough to allow room for the hemmed ends of the banner to be inserted into the wide opening of the arm. Slide the hemmed ends of the banner all the way back into the openings of both arms and tighten all "eight" of the black thumb screws firmly.

3.



Next - turn arms away from center until they are upside down from their original position. The banner should now cover the arms and still be face up.

4.



The banner is ready to be attached to the frame.

Manufactured in the USA by

**VOXPOP**

MARKETING SYSTEMS

10746 Worcester Highway P.O. Box 200


Berlin, MD 21811 800-386-9767

www.voxpopms.com


CONTINUED



5.




Screw-In Models




Hose Clamp Models

Pick up the banner - with the arms attached - and insert the Glide on the Dead End Arm into the top of the top Track as shown. The Arm should rest on the plastic Stop.

6.




Screw-In Models




Hose Clamp Models

Now pull the Live End Arm down and insert its Glide into the top of the bottom track. Insert the Tension screw through the hole in the white plastic block in the track, and up into the threaded hole in the Glide in the Arm.


7.




Screw-In Models



Hose Clamp Models



*FINISHED DISPLAY*



**TO REMOVE BANNER:**

1. Unwind Tension Screw & remove
2. Lift top Dead End Arm out of track
3. Lift bottom Live End Arm out of track
4. Loosen back thumb screws on Arms and remove banner

Tighten the Tension Screw clockwise until the banner is taut. If there is too much slack in the banner you may need to adjust the track position.

FOR DOUBLE SIDED POLE MTS - repeat for opposite side

**Questions?  
Problems?**

Call Voxpop at  
1-800-386-9767

or e-mail:  
service@voxpathms.com

**www.voxpopms.com**