


# Installation Instructions

## for Single or Multiple Cavity Toppers for Menu Boards


1



*Single Cavity Topper*

Using the bolts and wing nuts provided, attach the brackets to the frame as shown. The bolts insert through the holes from the front side (rear side shown).

OR




*Multi Cavity Topper*

Using the wing nuts provided, attach the brackets to the pre-set bolts in the frame as shown.

2


Position the frame on top of the menu board so the brackets are flush against the back, as shown. When it is in the proper position, make a mark along the back and sides of the track.

Remove the paper backing on the tape on the bottom side of the track and press it firmly onto the menu board aligned




3

Fasten the brackets to the back of the menu board with the self-tapping screws provided. (Screws are designed so a pilot hole is not necessary). Be sure the brackets are positioned so that the frame stands upright, as shown.




4

Insert graphics into slots as shown. Remove similarly.



*Single Cavity Topper  
Insert from side*



*Multiple Cavity Topper  
Insert from top*

Questions? Problems? Call Voxpop for assistance.  
**1-800-386-9767**  
 or e-mail [service@voxpathms.com](mailto:service@voxpathms.com)

Manufactured in the USA by

**VOXPOP**

MARKETING SYSTEMS

10746 Worcester Highway P.O. Box 200  
 Berlin, MD 21811 800-386-9767